



NADIR® NP030 P

“Nanofiltration” Membrane

NADIR® NP030 is a polyethersulfone (PES) membrane that exhibits nanofiltration characteristics when exposed to high pressure. Its stabilized molecular weight cut-off is in the range of 500-600 Daltons after operation at 40 bar (580 psi). NP030 membrane is durable enough to be used in concentrated acid environments and caustic recovery systems with a pH range of 0 - 14. NP030 membrane sheet is available in dry flat sheet rolls and is FDA compliant.

Membrane Characteristics

Membrane Chemistry	Backing Material	Na ₂ SO ₄ Rejection Bounds (%) ^a
Polyethersulfone (PES)	Polypropylene	80 – 95

Permeability LMH/bar (GFD/psi) ^b	Thickness (µm)	pH Range
≥ 40 (≥ 1.6)	210 – 250	0.0 – 14.0

a Test conditions: 5,000 ppm Na₂SO₄, 40 bar (580 psi), 20°C (68°F). Membrane specifications may change without notice as design revisions occur.

b Test conditions: Clean water, 40 bar (580 psi), 20°C (68°F).

Important Information

Standard Sizes: NADIR flat sheet membrane is available in an A4 sample size of 210 mm x 297 mm (8.27 in x 11.69 in) and in a nominal roll size of 150 m x 1016 mm (492 ft x 40.0 in). Custom lengths may be available on request.

Initial Flush: MICRODYN-NADIR recommends flushing membrane for 30 minutes and discarding permeate during the flush prior to operation.

Storage: Membrane shipped dry should be stored away from direct sunlight in a cool, dry place. Please see *Membrane Storage Guide – Flat Sheet Membrane* (TSG-O-011).

Solving Unmet Needs with Customized Products



Headquarters
MICRODYN-NADIR GmbH
Building D512
Kasteler Straße 45
65203 Wiesbaden
Germany
info@microdyn-nadir.de
www.microdyn-nadir.de

USA Office
MICRODYN-NADIR US, Inc.
93 South La Patera Lane
Goleta, CA 93117
USA
info@microdyn-nadir.com
www.microdyn-nadir.com/en
www.microdyn-nadir.com/trisep

China Office
MICRODYN-NADIR (Xiamen) Co. Ltd.
No. 66 Jinting North Road Xinglin
Xiamen, China 361022
infochina@microdyn-nadir.com

Singapore Office
MICRODYN-NADIR Singapore Pte. Ltd.
18 Tuas Avenue 8
639233 Singapore
info@microdyn-nadir.com