



TRISEP® UF10

PES Ultrafiltration Membrane

TRISEP® UF10 is a 10,000 Dalton molecular weight cut off (M.W.C.O.) polyethersulfone ultrafiltration membrane that is used in many different applications ranging from food and dairy process applications to water purification for dialysis and industrial water purification. UF10 membrane sheet is available in both dry and wet flat sheet rolls and is FDA compliant.

MEMBRANE CHARACTERISTICS

Membrane Chemistry	Backing Material	Nominal M.W.C.O. (Da)
Polyethersulfone (PES)	Non-Woven Polyester	10,000

Permeability LMH/bar (GFD/psi) ^a	Thickness (µm)	pH Range	Chlorine Tolerance ^b
≥ 73.9 (≥ 3.0)	160 - 200	1.0 – 12.0	200 ppm (sanitization) at pH ≥ 10.5

a Test conditions: Clean water, 1.4 bar (20 psi), 25°C (77°F), 15% recovery, pH 8.0. Membrane specifications may change without notice as design revisions occur.
 b For daily short term cleaning: maximum 50°C (122°F), 30 min.

IMPORTANT INFORMATION

Standard Sizes: TRISEP flat sheet membrane is available in a sample size of 305 mm x 1,016 mm (12 in x 40 in) and in a nominal roll size of 305 m x 1,016 mm (1,000 ft x 40 in). Custom lengths may be available on request.

Initial Flush: MANN+HUMMEL Water & Fluid Solutions recommends flushing membrane for 30 minutes and discarding permeate during the flush prior to operation.

Storage: Membrane is shipped dry unless wet membrane is specifically requested. Membrane shipped dry should be stored in a cool, dry place. If shipped wet, TRISEP membrane must remain sealed and refrigerated prior to use. Please see Membrane Storage Guide – Flat Sheet Membrane (TSG-O-011).

Contact

Europe
 Germany: +49 611 962 6001
 Italy: +39 0721 1796201
 info@microdyn-nadir.com

Americas
 USA: +1 805 964 8003
 sales.mnus@microdyn-nadir.com

Asia
 Singapore: +65 6457 7533
 China: +86 10 8413 9860
 waterchina@mann-hummel.com